


# Display System Assembly

**Use thread locking compound on all screws and inserts.**


**Use epoxy when locking supports in the top and bottom channels.**

**Screw studs into picture supports using thread locking compound.**

**Tighten all parts securly.**



**Drill mounting hole through channel and attach "L" bracket with stainless or plated M5 x 40 socket head bolt & nut.**



**Top View of "L" bracket**